DSM200 Digital Micro-Ohmmeter



Features

- 0-10A and 0-200A DC test current
- $0.1\mu\Omega$ resolution
- mV, A, and $\mu\Omega$ displayed simultaneously
- Direct Ohms reading at any current
- Large back-lit liquid crystal display
- Thermal and over-current protection
- Compact and portable
- Isolated RS232 interface for printer or PC connection
- Triple supply voltage
- Microprocessor controlled

T&R Test Equipment is a market leader in the field of high current micro-ohmmeters, manufacturing durable, accurate and user friendly units. The DSM200 is a high current micro-ohmmeter suitable for measuring very low resistances in a wide range of applications. The unit is equally suited to commissioning, maintenance, and production line environments. Contact resistances in circuit breakers, switch panels, isolators, and busbar joints are all easily and safely measured.

The back-lit display on the DSM200 is bright and clear with a wide viewing angle. The results of a test can be seen here as they appear on the display of the unit, showing current, sense voltage and resistance



The DSM200 is simple to operate, only requiring the user to switch the output on and set the test current. Selection of all ranges is fully automatic, and current, voltage and resistance are displayed simultaneously at all times. The resistance is calculated from the test current and sense voltage, and there is no need to set an exact test current to guarantee an accurate test result. To assist the user, all readings are held on the display when the output is switched off.



Connecting the DSM200 to a PC running the optional DSM*cal* software adds data capture and reporting functions to the unit, allowing test results to be exported directly to Excel or saved to a file. All results are time stamped, and a comment may be added to each test. Data capture can be controlled from the PC, and the resistance of a test object can be monitored over a period of time.

Alternatively, connecting a printer allows all of the test parameters to be printed automatically whenever the reading is held.



&R Test Equipment Ltd



Example Application: Testing Busbar Joint Resistance

Testing the joint resistances of a busbar using the DSM200 is a simple task. Before undertaking any testing, always ensure that power to the object under test is **OFF** and the object is earthed. The DSM200 should also be earthed.

With the output of the DSM200 off, connect the DSM200 output cables to the busbar, ensuring that all joint resistances to be measured are included in the circuit.

Connect the sense leads to the first joint to be measured, and switch the output of the DSM200 on. Increase the current to the desired

DSM200 Specification

Outputs

The DSM200 has two outputs. The 200A output is variable between zero and 200Adc, and is unsmoothed. The 10A output is smoothed, and has a ripple of less than 2% at 10A output current.

Range	Output	No load	Full load
	current	voltage	voltage
200A	0-200Adc	0-6.0Vdc	0-3.4Vdc
10A smoothed	0-10Adc	0-6.0Vdc	0-2.5Vdc

The DSM200 main output is rated at 200A for 5 minutes, 100A for 15 minutes, and 50A continuously. An off time of 15 minutes must be allowed after any of the above test times. These ratings are based on an ambient temperature of 25° C.

Protection and Safety

The unit is protected by electronic over current and duty cycle trips on the output, thermal trips on the power components, and fuses on the input and regulator. An earth terminal is provided for connection to a local earth.

The unit is designed to comply with BSEN61010, and is CE marked.

Supply Requirements

240V±10% 1 phase 50/60Hz. 1000VA Max. 220V±10% 1 phase 50/60Hz. 1000VA Max. 115V -6% to +10% 1 phase 50/60Hz. 1000VA Max.

Temperature Range

Storage -20°C to 60°C Operating 0°C to 45°C

Accessories

Spare fuses Supply lead Operating manual

Optional Accessories

Output lead set (3m, 5m, 8m, 10m available) DSM200 printer DSMlog software Lead set extension



level, and switch the output off. The readings will be held on the display.

Move the sense leads to the next joint (shown dotted on the diagram on the left), and switch the output of the set on and off to measure the resistance of the joint.

The process is even simpler if the optional DSM200 printer or a PC and DSMlog software is used. In this case the results are printed out or logged to the PC every time the reading is held by pressing the off pushbutton.

Metering

All metering on the unit is fully auto-ranging, selecting from four current ranges and three voltage ranges. The maximum voltages shown are peak values, and the maximum voltage that may be measured will be reduced if the test object is inductive. The resistance range is chosen from the current and voltage ranges as shown in the table below.

200A Output

	20.00A	200.0A
40.00mV	2000μΩ	200.0μΩ
400.0mV	$20.00 \text{m}\Omega$	2000μΩ
4000mV	$200.0 \text{m}\Omega$	$20.00 \text{m}\Omega$

10A Output

	1.000A	10.00A
40.00mV	$40.00 \text{m}\Omega$	4000μΩ
400.0mV	$400.0 \text{m}\Omega$	$40.00 \text{m}\Omega$
4000mV	4.000Ω	$400.0 \text{m}\Omega$

The maximum resistance that can be measured by the DSM200 at 200A is $17m\Omega$, increasing to 4Ω at a test current of 1A.

The current and voltage ranges have a metering accuracy of 0.6% of reading +5 digits, and the ohms ranges have an accuracy of 1.2% of reading + 10 digits over the range 1-200A.

All readings are held on the display when the output is switched off.

Mechanical Specifications

Dimensions 340 x 230 x 330mm Weight 21.4kg

Optional Lead Set Specifications

An optional lead set is available to complement the DSM200. The standard version is 3 metres long and includes two 25mm² high current leads terminated in copper battery clips and a screened sense lead terminated in copper crocodile clips.

Lead set weight 2.7kg (3m), 6.0kg (8m)

Note: Due to the company's continuous research programme, the information above may change at any time without prior notification. Please check that you have the most recent data on the product.

T&R Test Equipment Ltd, Keens Lane, Worplesdon, Guildford, Surrey, GU3 3JS, UK Tel: +44 (0)1483 235757 Fax: +44 (0)1483 235759 email: sales@trtest.com

www.trtest.com

T & R Test Equipment Ltd

DSM/0g v1.10

Data capture software for the DSM microhmeter Range

Features

- Capture data from your DSM microhmeter
- Operates under Windows 95
- All readings are time and date stamped
- Easily transferred into Microsoft Excel
- On screen help
 provided
- Auto-log facility
- Test location records for each reading
- Print the data on Windows printer

13.41.35 Non	Current Vollage Resistanc		60 A 53 mV 6L-u	Tar Te	stEq. Llog	ipment l PC Toterf Software	10 10	HELP
	GE	T NEW R	NEW READING			pressing £2/1 will browning the connection Connected or Con Part 2		
Daba Terr	Carloy	Vatade	Residence	Dram Cor		19) pro	ngë for com	at a

Applications

Routine testing and data logging resistance's of circuit breakers, motors and busbar joints

Description

DSM*log* is a Windows 95 program allowing test results from T & R Digital Sampling Microhmeters to be transferred to a PC. All readings are time and date stamped, and space is provided to log the location and other details of the test. Twenty readings may be stored, and these can be transferred to Microsoft Excel, printed out or saved to a text file for transfer to databases or word processors. The software is also able to log data from the instrument at pre-set time intervals in the range of ten seconds to one hour.

PC Specification

The following table gives a guide to the minimum and recommended PC specification to run DSM/og.

	Processor	Memory	Software
Minimum	486 DX	8MB RAM	Microsoft Windows 95
Recommended	Pentium	16MB RAM	Microsoft Excel 95 or 97

A demonstration version is available from our website (approx 1900k). Virtual DSM is required to run the demonstration version of DSM*log* - also available from our website.

www.tandrtest.co.uk

sales@tandrtest.co.uk

NB Due to the Company's continuous research program, the information above may change at any time without previous notification.

T&R Test Equipment, Keens Lane, Worplesdon, Guildford, Surrey GU3 3JS, UK Telephone: +44 (0)1483 235757 Fax: +44 (0)1483 235759